

RAIN RACER™ Application instructions

- 1) Clean glass thoroughly (For best results use [blue burnishing gel](#) as provided in the kit, This will not only deep clean the surface it will neutralise it ready for the polymer coating). Clean and then rinse with clean water, squeegee dry and buff.
- 2) To ensure all dirt and cleaner have been removed, buff with clean and dry kitchen towel.
- 3) **Polymer coating:** (Shake bottle well) Fold dry soft cotton cloth or paper tissue into small flat pad, apply directly onto pad. Wipe firmly in overlapping circles clockwise then anti – clockwise.
- 4) After 1 - 2 minutes apply second coat.
- 5) After 3 - 4 minutes wash off haze (dead solvents and polymers) using fresh cloth or tissue soaked in water.
- 6) Dry glass, buff and polish with dry cloth or tissue until crystal clear.
- 7) Re - apply as soon as required, [RAIN RACER™](#) can not be over applied as it does not produce build up's or overlaps, it simply self seals and produces a mono molecular film